



Ultrasonic Pest Repeller

PR-103

1. Plug the Makony Ultrasonic Pest Repeller to the power socket 2.5 - 4 feet from the floor, it should be vertical to the floor.
2. The device should be used 24 hours a day.
3. The device should be far from furniture, carpet, curtain etc.
4. Don't plug the device next to T.V, Radio, speakers or any sound device.
5. it's normal that the mouse and vermin will increase at first days of using the device. Because they are running away their living environment as they hear the ultrasonic sound.
6. To increase the effect, you should use several devices in order to cover the full area of your home, office etc.
7. CAUTION: DO NOT clean the device with water or damp cloth. DO Use dry and soft cloth.